


Performance-PCs.com

1701 R. J. Conlan Blvd. NE, Unit #5 Palm Bay, FL 32905, USA

Toll Free: 888-381-8222







www.performance-pcs.com sales@performance-pcs.com

Rexus PST-3 Digital Aluminum Power Supply Tester with LCD

\$23.95

Product Images









Features

- ATX PSU each output connectors check
- Tests 20-pin and 24-pin power supplies
- Tests SATA power
- Tests Pentium 4 power connector
- Tests PCI-Express power connectors
- Tests Xeon power connectors
- Tests Floppy drive connectors
- Tests standard 4-pin power supply connectors
- Accurate voltage indicator +/-V(+12V1/+5V/+3.3V/5VSB/+12V2/-12V)
- ATX P.G value display.
- Lower or higher P.G values alarm
- Lower voltage detected alarm.
- Over voltage alarm.
- No voltage detected alarm.
- Dimension : H * L *D : 64mm * 150mm * 18mm

Specifications

Manual:

1. Plug-in 24pin and plug-in (P4 / P6 or P8) connector into the tester before turn on power.

- - 20pin ATX PSU: use P4 connector.
- - 24pin ATX PSU: use P6 connector.
- - EPS PSU: use P8 connector.

2. Turn on your power supply

3. LCD show each voltage and P.G value on the screen automatic and you can hear 2 beep sounds.

4. ATX power output connector checking one by one.

- - If power output is working, the LED will light on
- - If power output failed, the LED will not light on.

5. Plug-in (HDD/Floppy) connector and check LED light. (+12V1/+5V).

- 6. Plug-in SATA connector and check LED light (+12V1/+5V/+3.3V).
- 7. Remove the connector after your checking.
- 8. DO NOT plug-in 2 connectors in to the tester at the same time. (Only 24pin and (P4/P6/P8)
- 9. Abnormal voltage detected will not display on the screen.
- 10. No voltage detect, "LL" will display on the screen.
- 11. Detected Voltage lower than Min. value, "LL" will display on the screen.
- 12. Detected voltage higher than Max. value, "HH" will display on the screen.
- 13. When detected voltage is lower than table value (A), will alarm.
- 14. When detected voltage is higher than table value (B), will alarm.
- 15. P.G value detected lower 100ms or higher 900ms, P>G value is abnormal and alarm.

When abnormal happened, it will alarm and relative digit blink on the screen.

Each voltage normal range: Reference field Low (A) and High (B) +/-5%: +5V, +5VSB, +3.3V +/-10%: +12V1, +12V2, -12V

Note:

The -5V DC output is took off from Intel ATX12V design guide since the 1.2 version.

1. The -5V usage was for last generation ISA slot. But the old ISA had been phased out since 1993~1994.

2. Neither P3 nor P4 systems will need -5V output.

	Normal Voltage Range		Display Voltage Range	
	Low (A)	High (B)	Min. (C)	Max. (D)
+5V	+4.75V	+5.25V	4.0V	6.0V
-12V	-11V	-13V	-10V	-14V
+12V1	+11V	+13V	+10V	+14V
+12V2	+11V	+13V	+10V	+14V
3.3V	+3.14V	+3.47V	+2.0V	+4.5V
5VSB	+4.75V	+5.25V	+4.0V	+6.0V

P.G Or	ms	990ms
--------	----	-------

Additional Information

Brand	Rexus
SKU	PST-3
Weight	0.5000
Color	Black
Psu Accessories	PSU Tester

